

外传 器使 书

XKC-KE200-PUB


目录

.....	2
.....	2
.....	2
.....	2
.....	2
.....	6
.....	7
.....	8
.....	8
.....	9
.....	10




号	型号	出信号


XKC-KE200-M 继电器输出原理及接线方法



YKC-KE200-MC继电器引脚图及接线方法





XKC-KE200-NPN（开关量型）原理及接线方法



棕 VCC
黑 OUT
蓝 GND

- 1.电源线 棕色
- 2.信号输出 黑色
- 3.电源负极 蓝色





高低电平信号输出：连接控制器或MCU的接线方法

